





FIELDHOUSE™ BLIND

Patent Pending

Instruction Manual




Be sure to follow these guidelines for using your Fieldhouse™

READ ALL INSTRUCTIONS and WARNINGS FIRST

Any questions or confusion regarding the use of this product contact our Customer Service Department at Ameristep® (810) 686-4035 before using.

COMPONENTS



FIELDHOUSE™ BLIND




PARTS LIST:

- 1 Fieldhouse™ Blind
(84" wide x 108" long x 19" high)
- Total Area: 23.5 square feet
- 1 Fieldchair
- 1 Set Plastic Ground Stakes
(10 Total) for Loose Ground
- 1 Set Metal Ground Stakes
(10 Total) for Frozen Ground
- 1 Camo Back Pack


- A. Draw-String Tie Enclosure
B. Camo Mesh Covering
C. Foot Stake Loops
D. Ground Stake Loops (10 Loops)
E. Integral Brush Pockets
F. Zippered Foot Opening
G. Decoy Slot



FIELDCHAIR COMPONENTS



LOCKING YOUR FIELDCHAIR



Locking the Decoy Bag Shelf:

Lock the metal arm over the rivet on each side of the shelf. Secure your decoy bag to the frame with the 2 adjustable straps on the back of the Fieldchair.

Unlocking the Decoy Shelf

Simply reverse by lifting up on the metal arm to release from the rivet.

RECOMMEND:

Practice setting up and taking down first before using in the field.



SET-UP


FIELDHOUSE™ BLIND



WARNING: The Fieldhouse™ Blind is constructed of Spring Steel - Open with extreme caution, holding the blind away from face, body and other people.

Step 1:

Unstrap Back Pack from the Fieldchair by unlocking the decoy bag shelf (as shown).



Unlocking the Decoy Shelf


Step 2:

- Remove your Blind from the back pack.
- Remove the two sets of Ground Stake Pouches, then remove the Fieldhouse™ Blind.

Step 3: Spread your Fieldhouse™ out on the ground.


Step 4: STAKING

Starting with number 1, stake your Fieldhouse to the ground. Continue staking around the rest of your Fieldhouse™.



! Tip

When staking no. 3 and 4, stretch the blind until it is tight. This will prevent wind flap.



Step 5: Stake 9 and 10, leaving the two longer stakes approximately 3 inches above the ground to provide foot clearance.

Step 6: After staking your Fieldhouse™, insert your Fieldchair in the interior. Remove covers from locking device and store in back pack pouch. Lock your seat adjustment and secure the seat straps to the inside of your Fieldhouse™.



Step 7: After securing your fieldchair inside of your Fieldhouse™, sit on your fieldchair inside your Fieldhouse™ to install the camo scrim.

Rear View



SECURING THE CAMO SCRIM

Step 8:

Close the upper camo scrim by fastening the two enclosures letting the rip-cord tail hang inside the blind. Secure the mesh with the straps to the framework for total concealment.

Inside Front View



Step 9:

The side of your Fieldhouse™ foot section unzips for clearing mud, dirt and any debris that may have collected.

Decoy Slot



TAKE-DOWN FIELDHOUSE™ BLIND

! Tip


It is recommended to have your back pack open and ready before starting take-down of your Fieldhouse™.

IMPORTANT:

BEFORE take-down of your Fieldhouse™, remove all ground stakes and make sure that it is **COMPLETELY DRY** and free from dirt and debris.


Step 1:

Overlap all loose material onto the spring steel section, the follow with Step 2.




Step 2:

Begin by lifting the sides of the framework.



Step 3:

Draw "B" and "C" towards the center tucking "B" behind "C".



Step 4: Overlap "B" and "C" and push rings down to "A" until they lay flat on the ground.

Step 5:

Pick up your folded "disk" and slide into your back pack.

Pack your ground stakes, and high wind tie-downs in the pouches provided. Store them with your Ameristep® Blind.

Attach the backpack to the back of the fieldchair with the straps provided.


Fold the decoy seat up and secure with the metal arms or leave down to carry your decoy bags and light-weight gear.

! Tip

Insert Hay, Straw, or natural brush in the integral brush pockets for a more secluded camouflaged hunting experience.

STORAGE & TIPS

- Store your Blind in a cool dry place
- Store your Blind free of dirt and any debris
- Never store your Blind wet or damp
- Avoid leaving your Blind outdoors for extended periods of time as it will cause unnecessary fading of the material.
- To stop any leakage, use seam sealer on all seams and silicon spray on the sidewalls.



Decoys and Decoy Bag
not included

See our full line of accessories on our website.
Replacement Parts are also available